
Network to Meridian Mail cabling

Cabling the Meridian Mail module is done only through the I/O panels. For a minimum configuration of one Meridian Mail module, two external cables are required. One is an NT8D73xx network loop cable and the other is an NTND91AA/AB Command Status Link (CSL) cable. Another CSL cable can be used to connect the Meridian Mail module to a local terminal. When more than one Meridian Mail module is configured, Meridian Mail modules must be daisy-chained together with an NT6D4415 DVS Daisy-Chain Cable. Only the primary node Meridian Mail module has CRT, CSL, and network connections. All other Meridian Mail modules have a network loop connection and the DVS daisy-chain cable. [Figure 50](#) shows the cabling of a Meridian Mail module to a network module.

Figure 50
Meridian Mail module cabling

